

PolyPad Tactiles Installation Kit

Product Images



Description

Complies to AS/NZS 1428 part 4, Building Code of Australia.

Installation Kit contents:

- 600x100mm cutting template,
- Masking tape (10m),
- Snap blade knife,
- Trowel,
- 1kg outdoor adhesive (2-part) - covers 0.75m sq or four 300 x 600mm poly pads.
- Installation instructions

*All items are reusable apart from adhesive and masking tape.