


Vehicle Wheel Nut Indicators - Ring

Product Images





26/4/24


Description

Wheel Nut Indicators are easily installed onto wheel lugs providing a quick visual warning if wheel nuts have become loose and are out of alignment.

With their plastic composition, they are also used, by deforming/melting when exposed to high temperatures, to help indicate signs of bearing or brake failure.

Ideal for 4WD's, trucks, buses, mine vehicles, trailers and caravans. Available in bags of 100 per size.

Products in this set



2