


Skipper™ Recycle Bin

Product Images



Description

The Skipper™ Recycle Bin is a robust and durable attachment for multi-purpose waste and recycling use.

The recycle bin can be used in the following ways:

- As a wall mounted refuse sack holder (via Skipper™ Wall Receiver Clip)
- Create a free standing safety station by attaching up to 2 Recycle Bins to the Skipper Post & Base System (via the Skipper Post Collar)

Each recycle bin is supplied with a selection of stickers to designate recycling type. Simply lift the inner ring and attach your plastic bag.

Connects to:

- Skipper™ Post Collar

- Skipper™ Post and Base System
- Skipper™ Wall Receiver Clip

Dimensions: 375mm (L) x 194mm (H) x 338mm(W) Weight: 1.1kg

Additional Information

Brand	Skipper™
-------	----------